ESSO-V Machine Tan


ESSO-V Machine Tan GUIDE

Packing List



Product Basic Parameters

Input voltage：	5~24VDC
Output voltage：	3V x 2~24VDC
Output current：	350mA, 1A/2ch
Output power：	3V x 2~24W
Output type：	Constant voltage
Sensitive field：	≈3m
Sensitivity angle：	30° ~ 120°



Prepare installation tools and materials

1. LED strip

Cut the LED light strip according to the demand, determine the length of each step LED strip. Note each step of the LED strip load current does not exceed 1A.




2. Power supply

Choose the voltage must be the same as the LED strip voltage.
And the power of the supply power ≥ LED strip total power*1.25.




3. Lead wire

Connecting controller and power supply.



4. LED Strip extension wire

Connecting controller and LED strip.



Wire diameter selection can refer to the following table. Such as connecting 20 steps, it is suggested to select not less than 2.5mm² wire to connect the power supply. Such as the controller connected light strip distance is within 10M, it is suggested to select not less than 0.5mm² light strip extension wire. Note that each end of the wiring at the wire stripping length recommended 6~7MM. And mark the corresponding port of the controller to avoid wrong connection.

Wire diameter	0.5	0.75	1.0	1.5	2.0	2.5	3.0
Cross-section area (mm²)	0.5	0.75	1.0	1.5	2.0	2.5	3.0
Output total current	≤2A	≤4A	≤10A	≤12A	≤15A	≤20A	≤30A

5. Electric soldering iron and solder

Soldering LED Strip Extension Cords and Light Strips.



6. Push switch (optional)

Use as manual switch to realize up/down lighting effects.
Push switch and PIR sensing can be used at same time.



Installation Steps

Take the installation of 8 steps of flow effect as an example, the parameter settings are:
Sequential light up, sequential light off, sequential light up, sequential light off, continuous turn on light, sequential turn off light, light sensing value set to 5, that is, the controller does not turn on light when the environment light is higher than 50 lumens.



Wiring: Use LED strip extension wire to connect controller and LED strip, Use wire that meets the wire diameter selection requirements to connect the power supply. Please note that the power supply is connected 220V mains, attention needs for differentiate plus and minus polarity.

Set language:



Lighting effect setting: Following the previous example, set step is 8, speed and brightness is 9, light on/off mode is sequential light on, sequential light off.

1. Step set



2. Light on/off mode setting

Light on/off mode list:

Display	Name
cS1	Sequential light on, sequential light off
cS2	Sequential light on, synchronized light off
cS3	Synchronized light on, sequential light off
cS4	Synchronized light on, synchronized light off



3. Speed Setting



4. Brightness setting



5. Light Mode Setting and Exit Setting

System Parameter Setting: Following the previous example, set light on and light off fade to 1s, and the controller does not turn on light when the environment light is higher than 50 lumens.

1. Enter system parameter Settings



2. Lights On fade setting



3. Lights Off fade setting



4. Light Sensitivity Setting




5. System parameter setting is complete, exit the system parameter setting interface



Controller light test run

Up light test





Down light test





Installation of Up and Down Sensor Heads

Confirm the LED strip wiring method is no error, the upward sensor head is installed at the location where the sensing trigger needs to be triggered before going up the stairs,
connect the up sensor head to the UP LED INPUT port of the controller.



Downward sensing head is installed at the location where the sensing trigger needs to be triggered before descending the stairs, connect the down sensor head to the DW PIR INPUT port of the controller.



Installation daylight sensor head

Daylight sensing head is installed in a position where it can sense ambient light, connected to the LIGHT INPUT port of the controller.



Long press the M key for 2s to enter the system parameter setting interface, check the light sense value: ? Displayed after the value indicates that the lumen value of the detected ambient light, that is, daylight sensing head is working properly.



Finally test for up and down sensing headers to trigger properly.



Connecting Push switch (optional)

The controller supports connecting the Push switch to trigger up and down lighting effects.
Connect the Push switch to the corresponding UP Push switch, DW Push switch terminals, GND and UP terminals, and the Push switch for triggering the down effect to the GND and DW terminals.



* Push switch and PIR sensor can be used at same time. For example, up stairs are triggered by the PIR sensor and down stairs are triggered with the Push switch.
During So after pressing the Push switch to trigger the effect, the PIR sensor is temporarily off and the Push switch operation ignores the threshold of the daylight sensor.


Skip damaged output channel

Such as this example to install 8 steps (S1~S8), 04 steps are damaged, you can long press the M, + and - key at same time for 2s, to enter the S0-step output setting.



At this time, the controller screen displays two lines of numbers, from left to right corresponds to the status of S1~S8 and the S1~S8 output channel, the number 1 means use, 0 means skip.

S1~S8 Step



1:1~32 Step

Short press M to switch to the 4th digit ?, press + to set 1 to 0, then long press M key for 2s or wait for 15s, save and exit setting.



Short press M to search to the fourth digit ?, press + to set 1 to 0.

Connect the output LED strips of channels 4-8 to the outputs of channels S-9, skipping channel 4, so that channels 5-8 replaces the previous channels 4-8.



Notice for installation of PIR sensor

1. The sensor head should be installed in dry environment as possible, avoiding wind and rain.
2. Do not install the sensor near heat sources, such as heaters, stoves, refrigerators, and other places that are sensitive to temperature changes.
3. We recommended that wall-mounted installation height is1~1.5 meters and that ceiling mounting heights no more than 3 meters.

PIR sensor detection scope (±15° Error):

Wall mounting



Ceiling mounting

* For wall mounting and ceiling mounting, note that the sensing holes are perpendicular to the direction of human movement.

4. When wiring the terminal and copper wire head should be tightened. If loose contact is poor, the contact resistance will increase, and the terminals will be hot when working with high power loads, which may cause damage and the corresponding channel will not work properly.